

Gebruik en onderhoud van de droger

Hierbij willen wij je nog enkele tips geven voor het gebruik/onderhoud van de droger.

- Reinig het pluizenfilter na iedere droogbeurt. Haal het filter uit de wasdroger en verwijder de grote stofdelen. Schoonmaken onder de kraan werkt het beste. Droog het filter wel af voordat je het terugplaatst in de droger. Gebruik één keer per maand een stofzuiger om het filter en de ruimte waarin je het filter plaatst volledig schoon te krijgen.
- Leeg na iedere droogbeurt het waterreservoir.
- Reinig de condensor 2 keer per maand. De pluizen kun je verwijderen met een stofzuiger. Spoel hem vervolgens af met water. Haal vervolgens een vochtige doek door de ruimte waar de condensor in zit en plaats hem weer terug.

We wensen je veel plezier met de droger!

Use and maintenance for the dryer

We would like to give you some tips for using/maintaining the dryer.

- Clean the fluff filter after each drying. Remove the filter from the dryer and remove the large dust particles. Cleaning under the tap works best. Dry the filter before putting it back in the dryer. Use a vacuum cleaner once a month to completely clean the filter and the room in which you place the filter.
- Empty the water reservoir after each drying cycle.
- Clean the condenser twice a month. You can remove the fluff with a vacuum cleaner. Then rinse it with water. Then run a damp cloth through the space where the condenser is located and place it back.

We hope you enjoy using the dryer!